










Standard Shell Colors

						
02 Spring	09 Silver	11 Teal	12 Steel Blue	13 Titanium	14 Warm Gray	
						
15 Black	17 Wet Sand	30 Translucent Frost	32 Translucent Soft Black	33 Translucent Navy	37 Translucent Ocean	39 Translucent Soft Yellow
						
41 Translucent Earth	50 Translucent Lime	52 Translucent Tomato				

Non-Standard Shell Colors (minimum 125)

Upcharges apply

						
01 Sun	03 Grass	04 Sky	05 Crocus	06 Dusk	08 Pearl	
						
10 Pale Green	16 White	18 Yellow	19 Orange	20 Espresso	21 Turquoise	22 Magenta
						
24 Moss	25 Red	34 Translucent Lilac	35 Translucent Lavender	36 Translucent Soft Plum	38 Translucent Celery	40 Translucent Cantaloupe




42
Translucent
Raspberry



44
Translucent
Grape




46
Translucent
Blueberry



48
Translucent
Turquoise




54
Translucent
Orange




56
Translucent
Soft Spring

Leg/Frame




PC00
Nickel




PC01
Onyx




PC05
Shale




PC22
Matte White



PC23
Dark Gray




PC24
Warm Gray



PC27
Bronze

Tablet

Available on Models 3513, 3523, 3623



BLK
Black